

3.35m x 3.35m x 2.79m / 1.98m CASTLE BOUNCE HOUSE USER'S MANUAL



⚠ WARNING

Read the assembly, installation, care, maintenance, and use instructions in this manual prior to assembling and using this Inflatable bounce house. Save this manual for future reference.

- **ADULT SUPERVISION REQUIRED.**
- **The Castle Bounce House should not be used by person weighing more than 200 pounds(90 kgs).**
- **Not recommended for use by children under 3 years old.**
- **The Castle Bounce House is for outdoor use only.**
- **Warning! Keep away from fire.**

IMPORTANT PRECAUTIONS



Do not land on head or neck.

Paralysis or death can result, even if you land in the middle of the jumping surface.

To reduce the chance of landing on your head or neck, do not do somersaults(flips).

Avoid bouncing when tired.



The Bounce House should not be used by more than two users at the same time.

Not recommended for use by children under 3 years old.

Multiple jumpers increase the chances of loss of control, collision, and falling off. This can result in serious injury to head, leg or neck.

! WARNING:

To reduce the risk of serious injury or death, read the following important precautions before using the Bounce House.

1. Read this manual carefully before using the bounce house. The owner of the Bounce House is responsible for making all users aware of the information in this manual.
2. The Bounce House is intended for home use only. Do not use the Bounce House in a commercial, rental, or institutional setting.
3. The Bounce House must not be set up or used in gusty or severe winds. Wind or air movement must be calm to gentle.
4. The Bounce House is for outdoor use only. Place the Bounce House on a level, smooth, soft surface such as grass. Do not use the Bounce House on a hard surface. Position the Bounce House as close as possible to a power source; do not use an extension cord.
5. Make sure that there is adequate clearance above and around the Bounce House. There must be no wires, tree limbs, walls, structures, fences, or other possible hazards near the Bounce House.
6. The materials used in the Bounce House are not fire retardant and may burn if exposed to flames. Keep the Bounce House away from flames and high heat sources.
7. Do not use the Bounce House unless it and the blower are properly anchored to the ground with the provided stakes. Wear proper eye protection while driving in the stakes. Make sure that the tops of the stakes are at ground level so they will not create a tripping hazard. In addition, cover the tops of the stakes, if necessary, so users will not be injured by falling onto the stakes.
8. Inspect the Bounce House, the power cord, and all other components before each use. If damage is found, do not use the Bounce House until it has been properly repaired.
9. The Bounce House should not be used by children under 3 years old. Children must always be supervised by adults while using the Bounce House.
10. The Bounce House should not be used by person weighing more than 200 pounds(90 kgs).
11. Before entering the Bounce House, remove shoes, eyeglasses, and sharp or breakable objects. In addition, remove jewelry or other objects that could get caught on the netting.
12. Climb head first into the Bounce House. Crawl feet first out of the Bounce House. Do not jump onto the Bounce House or off it. Do not use the Bounce House as a springboard to other objects.
13. Always close the door of the netting while the Bounce House is in use. Do not bounce against the door.
14. Do not attempt or allow somersaults. Doing so can result in a broken head, neck, back, or leg. Landing on the head or neck can cause serious injury, paralysis, or death.
15. The Bounce House uses a mains powered fan to maintain pressure. Only to be used by competent adult.

16. Do not jump against or pull down on the sides or corners of the Bounce House from the inside or the outside. Do not stand on the Bounce House while you are outside of it.
17. Misuse and abuse of the Bounce House is dangerous and can cause serious injuries or death.
18. Do not turn off the blower while the Bounce House is in use. If the blower stops unexpectedly, make sure that all users exit the Bounce House immediately.
19. Keep children away from the blower, the air inlet, the air outlet, and the power cord at all times.
20. Always turn off the blower and put the Bounce House away when it is not in use.
21. Keep the Bounce House and the blower dry. Never put the Bounce House in a pool. Do not use the Bounce House if it is wet.
22. Place the Bounce House on a free-space boundary free from branches, sharp corners, fences, obstacles where a child could fall upon. Siting must always be on soft ground
23. The Bounce House must never be used in a partially-inflated state.
24. Before and during use, check for air loss and re-inflate before allowing play to continue.
25. All inflation / deflation and assembly should be carried out by a competent adult.
26. Adult supervision required.
27. The blower is not a toy. Use under the direct supervision of a competent adult.
28. Do not leave children unattended at any time.
29. This is not an aquatic toy. It is not to be used in water.
30. Helmets or other headgear should not be worn whilst playing on bounce house.
31. Loosen or baggy clothing, or clothing containing long cords should not be worn whilst playing on Bounce House.
32. Keep pets away from this product.
33. Remove shoes, eyeglasses and sharp objects before entering.
34. Bounce away from others and sides, especially the openings.
35. Do not set up when windy.
36. Set up as near to power source as possible.
37. Keep hands away from net.
38. Do not jump on or off the Bounce House.
39. No flip or wrestling.
40. Surface washable only.
41. Do not leave blower outside overnight or in wet or damp conditions.
42. The blower should be securely affixed to the ground before use.
43. Users should be advised to check the product and all its anchorage points before and during use, and to re-inflate or re-secure a appropriate.

KEEP THESE INSTRUCTIONS


GROUNDING INSTRUCTIONS

⚠ DANGER:

Improper connection of the equipment-grounding connector can result in an increased risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product - If it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This product must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with cord having an equipment-grounding conductor and a grounding plug. Plug the outlet that is properly installed and grounded in accordance with all local codes and ordinances.

This product is for use on a nominal 240 volt circuit.



SETUP

Follow the steps below to set up the Bounce House. A hammer and eye protection (not included) are required.

1. Unzip the carrying case and remove the Bounce House and the accessories.
2. Unfold the Bounce House.
3. Extend the long air tube as shown. Set the blower near the end of the air tubes, with the mouth of the blower pointed toward the Bounce House. Using the two small stakes, secure the blower to the ground.



Using the two slamm stakes to secure the blower to the ground.

SETUP

Follow the steps below to set up the Bounce House. A hammer and eye protection (not included) are required.

4. Fit the end of one of the air tubes over the mouth of the blower, and tighten the drawstring on the air tube. Then, tighten the drawstring on the other air tube.
5. Plug the blower power cord into the grounded outlet properly. Press the on/off switch on the blower to turn on the blower. The Bounce House will inflate. Note: The blower must be left on while the Bounce House is in use.



6. Make sure that the Bounce House is positioned so the air tubes are straight. Using the included stakes, secure each strap on the Bounce House to the ground. The Bounce House is now ready to use.



HOW TO PUT THE BOUNCE HOUSE AWAY

1. Make sure that all users are out of the Bounce House. Press the on/off switch on the blower to turn off the blower. Loosen the drawstring on the air outlet tube.
2. Disconnect the air inlet tube from the blower. Unplug the blower power cord.
3. When the Bounce House has deflated completely, remove the stakes from the Bounce House and the blower. Make sure that the Bounce House is completely dry, and then fold it. Slide the carrying case over the Bounce House, turn the carrying case right-side-up, insert the accessories into the carrying case, and close the zipper.
4. Store the Bounce House and the blower in a dry location. Cover the blower to protect it from dust.
5. Do not leave the blower outside overnight or in wet or damp conditions.






CARE & MAINTENANCE

To clean the outer surfaces of the Bounce House, use a hose and a soft cloth. Do not machine wash the Bounce House or use a pressure washer. Make sure that the Bounce House is completely dry before you put it away. Always deflate Bounce House after use, and store indoors.

Users must be advised to regularly inspect the product for wear and tear.

Users must be discouraged from attempting any unauthorised modification.

PART LIST

Key Listing	A	B	C	D	E
Picture					
Description	Bounce House	Blower	Plug and cable	Plastic stake for blower (Short)	Plastic stake for bounce house (Long)
Qty	1	1	1	2	4

ORDERING REPLACEMENT PARTS

To order replacement parts, visit our Web site or call our Customer Hot Line (see front page). To help us assist you, please provide the following information when calling:

- the MODEL of the Inflatable Bounce House
- the NAME of the product
- the KEY NUMBER and DESCRIPTION of the part (see the PART LIST above)
- the quantity needed
- the desired method of shipping

**For a full range of accessories
and replacement parts
call 0844 800 4060**